

1. Two people gently lift and turn sofa or chair upside down as shown.
2. Remove the plastic shipping legs and remove the pre-installed wood screws from bottom of frame, as shown in DIAGRAM 1.
3. Place the metal leg on the corner of the frame. Line up center hole on leg with hole on frame and insert the bolt with lock washer, as shown in DIAGRAM 2. Make sure the leg is pressed tightly against the frame. Tighten the bolt.
4. Insert screws as shown in DIAGRAM 3 and, using a phillips head screwdriver, tighten screws into the same holes from which they were removed in *Step 2*.
5. Two people gently lift and turn the sofa or chair over onto the legs.

needed for assembly:

